

# Peel & Stick Stone™

## Installation Instructions

### **Tools Required:**

Tile saw, Tape measure, caulk gun, pencil & level (P&S can be installed over most surfaces).

### **Included In Box:**

Special high temperature adhesive, 7 SQ FT of stone.

**Step #1:** Make sure the wall or surface you are gluing to is clean. You can use “denatured alcohol” in a spray bottle and wipe with a cloth towel. Allow to dry before proceeding.

**Step #2:** A board may be used under the first row for the stone to rest upon to get started straight and level. Make a level line at the top of the first row to align the stones straight and level.

**Step #3:** Prepare the caulking gun with a tube of the “special high temperature adhesive” (substitution of other adhesives voids all warranties).

**Step #4:** Begin by first installing the corners or bull nose ends on the first row. Place 2-6 “quarter” size round dollops, depending on the size of the stone, of adhesive on the back of each stone between the adhesive pads.

**Step #5:** Remove the paper from the adhesive pads and stick the stone to wall at the desired locations. The adhesive will set in about an hour and completely cure in 24 hours. The tape will hold the stone in place while the adhesive sets and cures.

**Step #6:** Fill the area between the corners or bull nose ends with the flat straight pieces using the same caulking process as described in “Step 5”.

**Step #7:** The last flat section will need to be cut for length. Measure and cut on the tile saw (without using water). Apply adhesive and fit into place as described in “Step 5”. Continue one row at a time checking with the level to keep the stone straight and aligned until the project is completed. If you start to get out of level, small wooden shingle shims can be used to correct the situation.

**Accessories:** Several trim options are available such as arches, keystone, electrical stones, and cap stones and install in the same manner.

**Sealer:** For additional protection and longevity, please use our Repel 10™ Sealer.

**Note:** If you get any adhesive on the stone, allow it to dry before trying to remove it.

**Summit Stone  
Solutions**

780 N Warm Springs Rd  
Salt Lake City, UT 84116  
801.355.3221